

CARPET INSTALLATION

Substrate for all carpet fiber types. If existing wall, consider using DuPont® Teflon® Advanced® for wall.

For low-pressure sprayer applications pumped to 30-40 psi:

1. Dilute product by mixing one part Teflon® Advanced with four parts water.
2. Apply with an 800K Teflon jet nozzle at the rate of 200 sq. ft. per gallon of diluted product. Do not over-saturate.

For in-line sprayer application from truck systems:

1. Use manufacturer's recommended nozzles or nozzle adjustments to accomplish a dilution rate of one part Teflon® Advanced to four parts water.
2. Use an 800K Teflon jet nozzle. Smaller nozzles are not to be used with truck mount equipment. Pressure at truck mount should never exceed 300 psi at pump outlet.

For other applications methods:

1. Spray with 50% pre-fogging spray pattern.
2. After spraying carpet, touch on roller.
3. If Teflon® Advanced has been sprayed over any hard surfaces such as linoleum, hardwoods, tile, etc., wipe off before drying occurs.
4. Allow carpet to dry before removing one of carpet.
5. To prevent material accumulation in spray equipment, clean with fresh water after each use.

The DuPont® Teflon® Advanced® is registered trademark of DuPont.

Contents: One Gallon

IMPROVED

DuPont™ Teflon® Advanced

carpet and upholstery protector

DuPont Chemical Solutions Enterprise
Wilmington, Delaware 19898 U.S.A.



FREEZE/THAW STABLE **Medical Emergencies: 1-800-441-3637**



The members of